





- 1) The booster bars (M, N) are installed on the seat frame (D) as shown in the figure, and fastened with M6X20 (O) bolts.
- 2) Step on the rope, hold the booster bars on both sides, expand the seat frame fabric.
- 3) Remove the booster bars after expansion.
- 4) Cut rope, take off the booster bars and throw them after finishing.




- 1) Put seat frame upside down, assemble the arms into matching holes.
- 2) Tighten the M6x20 Bolts(O) & Washers (O-1) with an allen key (R).
- 3) Insert the seat height adjustment lever (H) into the corresponding hole in the tray.








- 1) Place the seat frame hole on top of the gas lift.
- 2) After installation is complete, sit on a chair to make it fully jammed.



- 6
- 1) Unfold the undeployed back frame (C) with the
- rope and install it on the tray.

 2) Tighten the M8x20 Bolts(P) & Washers (P-1) with an allen key (R).
- 3) Cut and throw the rope after finishing.



- Install the headrest height adjustment lifter (G) into the upper part of the seat back.
 Tighten M8x12 Bolts (Q), cover with silicone pad(B).
 For headrest installation, please refer to the headrest(A) installation tag.

